

Ref.: A19705 OVEN DEGREASER KING 750 ML

Quickly and efficiently cleans ovens, grills, etc.

- ✓ Removes all traces of grease
- ✓ Suitable for indirect food contact



SPECIFICATIONS

<u>pH:</u> 13 +/- 0.5	<u>Scent:</u> citrus
<u>Density:</u> 1.06 +/- 0.02	<u>Appearance:</u> opalescent liquid
<u>PE:</u> > 61°C	

APPLICATION

For quick and efficient cleaning of ovens, grills, rotisseries, barbecues, stoves, fryers, hoods and kitchen accessories.

Can also be used for cleaning dishes and kitchen accessories.

Quickly eliminates grease, cooked fats and charred debris.

Contains: Caustic soda, less than 5% anionic surfactants, perfumes.

Applied with a pistol, the foam product adheres to vertical surfaces for longer contact.

RECOMMENDED FOR

- Kitchens, hospitality
- Cleaning companies
- retirement homes, hospitals,
- Schools
- Industries
- Offices

INSTRUCTIONS FOR USE

Heat the oven for 3 to 5 minutes and turn it off. Spray on directly 20 cm from the surface to be treated.

Leave to work for 10 minutes, then clean and rinse with a damp sponge.

Do not apply to alkaline-sensitive surfaces (like aluminum, etc.).

Do not use on self-cleaning ovens.

Rinse well with clear water when using on kitchen accessories and plates.

**For surfaces in contact with food, it is compulsory to rinse with drinking water.*

PACKAGING

Packaging unit: 750 mL spray

Sales unit: Box of 6 units

Pallet size: 630 units – 105 boxes

REGULATIONS

FOR INDIVIDUAL AND PROFESSIONAL USE

Dangerous. Follow precautions for use.

Refer to the safety data sheet (SDS). Available on request.

Our data sheets are prepared with current knowledge and are subject to modifications. Photo non-binding.

26/05/2023 Index 3.4