



Ref.: A16074 MANUAL DISHWASHING DETERGENT SOPROMODE 1L

For manual washing of crockery and kitchen utensils.

- ✓ **Lemon scented**
- ✓ **Suitable for indirect food contact***



SPECIFICATIONS

pH: 8.5 +/- 0.5

Scent: lemon

Appearance: Slightly viscose

APPLICATION

Product especially designed for the manual washing of kitchen utensils: crockery, glassware, cutlery, pots and pans, worktops.

Has a pleasant lemon scent.

** To clean surfaces which may come into contact with food, it is compulsory to rinse with drinking water.*

RECOMMENDED FOR

- Kitchens
- Hospitality
- Cleaning companies
- Local authorities

INSTRUCTIONS FOR USE

Remove any significant waste.

Dilute the product in warm water, preferably about 10 to 20 mL for 5 liters of water, depending on how soiled the dishes are.

Wash, rinse with drinking water.

Leave containers to drain and dry.

PRECAUTIONS FOR USE

Keep out of reach of children. Do not use this product for any other purpose than for which it is intended. Not frost resistant.

PACKAGING

Packaging unit: 1 L container

Sales unit: Box of 12 units

Pallet size: 600 units – 50 boxes

REGULATIONS

FOR PROFESSIONAL USE

Dangerous. Follow precautions for use.

Refer to the safety data sheet (SDS). Available on request.

Our data sheets are prepared with current knowledge and are subject to modifications. Photo non-binding.

19/04/2023 Index 3.2